

Instruction Sheet

MPR SERIES


M-Series Power Module



M-15A



M-20A



M-20IGA

THANK YOU

Thank you for purchasing an M-Series Power Module. Please read these instructions thoroughly before installing / assembling this product.

PRODUCT FEATURES

- Build a NRTL Listed custom power strip with off-the-shelf parts.
- Modules can be controlled by advanced RLM Series modules with the use of a JMS Series jumper.

Middle Atlantic Products

To reduce the risk of electrical shock, disconnect power before servicing.

To be used indoors in dry location only.

THREE M SERIES MODULES ARE AVAILABLE

- M-15A - 15 AMP circuit
- M-20A - 20 AMP circuit
- M-20IGA - 20 AMP circuit with isolated ground

FUNCTIONS

- The M-Series Module is designed to work in conjunction with Middle Atlantic Products MPR System.
- Power connects via genderless 30 Amp T-Series tails and J-Series jumpers. (Purchased separately)
- The M-Series Module is always on when 120V AC power is applied.
- These modules can be switched on / off when used in conjunction with RLM Series modules with the use of a JMS Series jumper (purchased separately).

INSTALLATION

All module ground wires MUST be connected to the facility ground and bonded to the ground stud in J-Box. (Except Isolated Ground Modules, see below)
When screwing the module to the raceway, use a hand-held screwdriver and do not overtighten.

ISOLATED GROUND MODULES (M-20IGA)

Isolated Ground Modules require a separate isolated ground conductor (from source supply) directly to the green module wire. This grounding conductor MUST NOT be connected to ground stud in the J-Box.

For safety, the MPR Raceway MUST be grounded to standard building ground. This can be accomplished with metallic conduit connection and / or grounding conductor. This grounding conductor (if provided) must terminate on the grounding stud in the J-Box only.

WARRANTY

Middle Atlantic Products, Inc. (the "Company") warrants the M Series Module to be free from defects in material or workmanship under normal use and conditions for a period of (3) three years from date of shipment by the company.

The Company's entire liability to the purchaser, and the purchaser's (or any other party's) sole and exclusive remedy, under this warranty shall be limited, at the Company's option, to either (a) return of and refund of the price paid for, or (b) repair or replacement at the Company's factory of the products purchased, or any part or parts thereof, which the Company has determined to be defective after inspection thereof at the Company's factory.

This warranty does not cover damage due to acts of God, accident, misuse, abuse or negligence by parties other than the Company, or any modification or alteration of the products. In addition, this warranty does not cover damage due to improper handling, assembly, installation or maintenance.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF THE PRODUCTS PURCHASED, EVEN IF THE COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE COMPANY'S LIABILITY TO THE PURCHASER (OR ANY OTHER PARTY) HEREUNDER, IF ANY, SHALL IN NO EVENT EXCEED THE PURCHASE PRICE OF THE PRODUCTS PAID TO THE COMPANY.

Corporate Headquarters
Corporate Voice 973-839-1011 - Fax 973-839-1976 / International Voice +1 973-839-8821 - Fax +1 973-839-4982
middleatlantic.com - info@middleatlantic.com

Middle Atlantic Canada
Voice 613-836-2501 - Fax 613-836-2690 / middleatlantic.ca - customerservicecanada@middleatlantic.ca

Factory Distribution
USA: NJ - CA - IL Canada: ON - BC

At Middle Atlantic Products we are always listening. Your comments are welcome.