


INSTRUCTION SHEET

PB-DWR

POWER MOUNTING BRACKET



THANK YOU

Thank you for purchasing the PB-DWR power bracket. Please read these instructions thoroughly before installing / assembling this product.

PRODUCT FEATURES


- Mounts vertical power strips in DWR and SR Series wall rack.
- Works with mounting clips for PDT Series and PD Series power strips.



Middle Atlantic Products

I-2404

Rev F




MOUNTING OPTION # 1

PDT Series Thin Power Strip


- 1) Attach the mounting clips to the PB-DWR power brackets.
- 2) Mount the PB-DWR power brackets to the desired upper and lower positions as shown.
- 3) Snap the power strip into the clips.

MOUNTING OPTION # 3

PD Series Power Strip



- 1) Mount the quick clips to the PB-DWR power brackets.
- 2) Mount a PB-DWR power bracket to the desired upper position as shown. A minimum of one inch spacing (between power strip top and rack top) is required to allow power strip installation and removal.
- 3) Slide power strip bridge lance onto upper quick clip and let the power strip hang.
- 4) Slide the lower PB-DWR power bracket with quick clip onto the bridge lances to line up with the proper mounting holes.
- 5) Mount the lower PB-DWR power bracket.



Quick clip (2 provided) for hard-wired PD Series strips. Bend tab after hanging power strip to conform to UL Listing.

WARRANTY

Middle Atlantic Products (the "Company") warrants the PB-DWR Power Bracket to be free from defects in material or workmanship under normal use and conditions for the lifetime of the product.

The Company's entire liability to the purchaser, and the purchaser's (or any other party's) sole and exclusive remedy, under this warranty shall be limited, at the Company's option, to either (a) return of and refund of the price paid for, or (b) repair or replacement at the Company's factory of the products purchased, or any part or parts thereof, which the Company has determined to be defective after inspection thereof at the Company's factory.

This warranty does not cover damage due to acts of God, accident, misuse, abuse or negligence by parties other than the Company, or any modification or alteration of the products. In addition, this warranty does not cover damage due to improper handling, assembly, installation or maintenance.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF THE PRODUCTS PURCHASED, EVEN IF THE COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE COMPANY'S LIABILITY TO THE PURCHASER (OR ANY OTHER PARTY) HEREUNDER, IF ANY, SHALL IN NO EVENT EXCEED THE PURCHASE PRICE OF THE PRODUCTS PAID TO THE COMPANY.

Corporate Headquarters

Corporate Voice 973-839-1011 - Fax 973-839-1976
International Voice +1 973-839-8821 - Fax +1 973-839-4982
middleatlantic.com - info@middleatlantic.com

Middle Atlantic Canada

Voice 613-836-2501 - Fax 613-836-2690
middleatlantic.ca - customerservicecanada@middleatlantic.ca

Factory Distribution

USA: NJ - CA - IL Canada: ON - BC

At Middle Atlantic Products we are always listening. Your comments are welcome.

Middle Atlantic Products is an ISO 9001 and ISO 14001 Registered Company.