

Model RMPWMK3 Installation Instructions

Introduction

The RMPWMK3 provides a secure and attractive means to remotely mount the ProMatrix™ Models PM3000 and PM3180 control panels. The mounting kit can accommodate single-gang box mounting or mounting directly to the surface of a wall. User-supplied 6-conductor interconnect cable can be routed either in wall or surface mounted. This kit includes the cable adapters necessary for connecting the user-supplied cable to the main ProMatrix unit.

Contents of Kit:

1 - Sub-bracket	6 - Wire nuts
1 - Mounting plate	4 - Sheet metal screws (black, 3/8")
1 - Modular telephone block	4 - Wall anchors and screws
1 - 6-foot modular telephone cord	2 - Machine screws (6-32 X 3/4")

Step 1. Cable Size & Routing

The RMPWMK3 requires user-supplied 6-conductor cabling from the mounting location of the control panel to the location of the main unit. A modular telephone jack and 6-foot telephone cable complete the connection to the main unit.

Once the necessary cable length is known, use the table below to determine the minimum conductor gauge to use.

Wire Gauge (AWG)	Wire Resistance (Ω /1000ft)	Max. Cable Length (feet)
26	40	100
24	25	160
22	16	250

Note: Route the cable away from electrically noisy items like large motors, transformers, fluorescent ballasts and light dimmer circuits.

Step 2. Mounting the Sub-bracket

Gang-box mounting: Position the sub-bracket as shown in Figure 1. Route the cable through the large hole in the sub bracket and use two (2) 6-32 X 3/4" machine screws to attach the sub bracket to the gang box.

Surface mounting: Position the sub bracket against the wall in the desired mounting location (see Figure 1 for the correct orientation of the sub bracket). Make sure that the sub bracket is level and mark the location of the 4 mounting holes in the sub bracket. Install the 4 wall anchors in these locations and mount the sub bracket. Fish the cable through the large hole in the sub bracket if in-wall wiring is used. If using surface-mounted cable, make sure the cable will line up with the notch in the mounting plate and is secured to the wall.

Step 3. Wire and Attach the Mounting Plate

Write the colors of the conductors of the user-supplied cable in the spaces provided in Figure 2. Using the supplied wire nuts, make connections to the wires on the black mounting plate as shown on Figure 2. Double check the connections to ensure that they are secure and that they match the colors written in Figure 2.

Using the 4 black sheet metal screws (3/8"), attach the mounting plate to the sub bracket (see Figure 1). Check that the mounting plate is level. There is play in both the sub bracket holes and mounting plate holes to allow some leveling adjustment. Snap the ProMatrix control panel onto the wall mount assembly.

Step 4. Main Unit Connections

Mount the modular telephone block so that the 6-foot telephone cable will reach the main unit telephone connector on the back. Again follow Figure 2 and connect the cable wires to the modular telephone block. Connect the modular telephone cable between the unit and the block.




Figure 1




Figure 2